

SOAP DISH / TWO VERSIONS

Original model geometry / nominal dimensions in mm / print at 100%

DRAINING L


165.5 × 99.9 × 18.9 mm






DRAINING M

141.0 × 85.2 × 15.9 mm






DRAINING S

120.6 × 72.8 × 14.7 mm





USE + FIT

Draining: side outlets release runoff. Closed: base collects drips; it is not specified as watertight.

Choose S, M or L to suit your soap. These are separate one-piece designs, not a removable tray system.

Leave drainage outlets clear; rinse the ribs and empty collected water regularly. Dimensions are external.


SOAP DISH / TWO VERSIONS

Original model geometry / nominal dimensions in mm / print at 100%

CLOSED L


165.5 × 99.9 × 18.9 mm






CLOSED M

141.0 × 85.2 × 15.9 mm






CLOSED S

120.6 × 72.8 × 14.7 mm





USE + FIT

Draining: side outlets release runoff. Closed: base collects drips; it is not specified as watertight.

Choose S, M or L to suit your soap. These are separate one-piece designs, not a removable tray system.

Leave drainage outlets clear; rinse the ribs and empty collected water regularly. Dimensions are external.